


1105 SCREWDRIVER

EXPLODED VIEW



PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.	Index Number	Part Number	Description	Qty.
1	956148-01	Handle	1	10	956148-10	Rear Plate Spacer	1	34	956148-34	Ball Bearing (6001)	1
2	956148-02	Reverse Valve	1	11	956148-11	Rear Plate	1	36-1	956148-361	Roll Pin (2 x 14)	1
3	956148-03	Reverse Valve Bushing	1	12	956148-12	Cylinder	1	37	956148-37	Rotor	1
4	956148-04	Reverse Lever	1	13	956148-13	Front Plate	1	41	956148-41	Rotor Gear	1
5	956148-05	Valve	1	14	956148-14	Gear Casing	1	42	956148-42	First Gear Cage	1
6	956148-06	Valve Rod Bushing	1	15	956148-15	Gear Casing Cover	1	43	956148-43	First Planet Gear	3
7	956148-07	Throttle Trigger	1	16	956148-16	Bit Sleeve	1	44	956148-44	Anvil	1
8	956148-08	Air Inlet Bushing	1	17	956148-17	Bit Spacer	1	45	956148-45	Second Planet Gear	3
	1105-RK	Repair Kit (Parts available in kit only)	1	18	956148-18	Allen Head Dog Point Screw (M4 x 6)	1	46	956148-46	Spacer	1
9		Silencer	1	19	956148-19	Pin (3 x 28)	1	47	956148-47	Gear Cage Spacer	1
20		Pin (2 x 23)	1	21	956148-21	Roll Pin (2 x 6)	1	48	956148-48	Roller Pin (3 x 8)	6
25		Spring (3 x 5)	1	22	956148-22	Roll Pin (2 x 10)	1	49	956148-49	Ball (1/8)	1
29		Inner Snap Ring (9)	1	23	956148-23	Roll Pin (2 x 16)	1				
31		Ball (1/8)	1	24	956148-24	Spacer (18 x 12.1 x 1)	1				
33		Ball Bearing (606)	1	26	956148-26	Spring (13.5 x 11)	1				
35		Miniature Ball Bearing (696)	1	27	956148-27	Cone Spring (6.8 x 8.5 x 8)	1				
36		O-Ring (SNS14)	1	28	956148-28	Snap Ring (11.7 x 1.0)	1				
38		Blade	5	30	956148-30	Outer Snap Ring (12)	1				
				32	956148-32	Ball (1/4)	1				



10000 SE PINE
PORTLAND, OR 97216
503-254-6600
FAX 503-255-2615

When ordering spare parts, please specify tool type, part number, and description

FOOTNOTES