


# EPTS-34021-25Q TORQUE CONTROLLED SCREWDRIVER

## EXPLODED VIEW



## PARTS LIST — FOR REFERENCE ONLY

Index Number	Part Number	Description	Qty	Index Number	Part Number	Description	Qty.
1	EPTS-34021-25Q-1	Housing	1	39	EPTS-34021-25Q-39	Steel Ball	3
2	EPTS-34021-25Q-2	Reverse Valve	1	40	EPTS-34021-25Q-40	Spring	1
3	EPTS-34021-25Q-3	Spring	1	41	EPTS-34021-25Q-41	Standard Anvil	1
4	EPTS-34021-25Q-4	Valve Bushing	1	42	EPTS-34021-25Q-42	Pin	3
5	EPTS-34021-25Q-5	Trigger	1	43	EPTS-34021-25Q-43	Band	1
6	EPTS-34021-25Q-6	Spring Pin	1	44	EPTS-34021-25Q-44	Steel Ball	3
7	EPTS-34021-25Q-7	Valve Stem	1	45	EPTS-34021-25Q-45	Central Clutch	1
8	EPTS-34021-25Q-8	Bushing	1	46	EPTS-34021-25Q-46	Washer	1
9	EPTS-34021-25Q-9	Pin	1	47	EPTS-34021-25Q-47	Spring	1
10	EPTS-34021-25Q-10	Pin	1	48	EPTS-34021-25Q-48	Spring Collar	1
11	EPTS-34021-25Q-11	Shut-off Valve	1	49	EPTS-34021-25Q-49	Adjustment Lock Ring	1
12	EPTS-34021-25Q-12	Rear Plate Space	1	50	EPTS-34021-25Q-50	Adjustment Nut	1
13	EPTS-34021-25Q-13	Washer	1	51	EPTS-34021-25Q-51	Retainer	1
14	EPTS-34021-25Q-14	Throttle Valve Plunger	1	52	EPTS-34021-25Q-52	Bushing	1
15	EPTS-34021-25Q-15	Ball Bearing	1	53	EPTS-34021-25Q-53	Release Sleeve	1
16	EPTS-34021-25Q-16	Rear End Plate	1	54	EPTS-34021-25Q-54	Spring	1
17	EPTS-34021-25Q-17	Cylinder	1	55	EPTS-34021-25Q-55	Washer	1
18	EPTS-34021-25Q-18	Spring Pin	2	56	EPTS-34021-25Q-56	Retainer	1
19	EPTS-34021-25Q-19	Rotor Blade	5	57	EPTS-34021-25Q-57	Clutch Housing	1
20	EPTS-34021-25Q-20	Rotor	1	58	EPTS-34021-25Q-58	Rubber Ring	1
21	EPTS-34021-25Q-21	Front End Plate	1	59	EPTS-34021-25Q-59	Air Inlet	1
22	EPTS-34021-25Q-22	Spring Pin	1	60	EPTS-34021-25Q-60	Exhaust Deflector	1
23	EPTS-34021-25Q-23	Ball Bearing	1	61	EPTS-34021-25Q-61	Muffler Element	1
24	EPTS-34021-25Q-24	Washer	1	62	EPTS-34021-25Q-62	Air Inlet	1
25	EPTS-34021-25Q-25	Planet Gear	3	63	EPTS-34021-25Q-63	Spring	1
26	EPTS-34021-25Q-26	Front Gear Head	1	64	EPTS-34021-25Q-64	Throttle Valve	1
27	EPTS-34021-25Q-27	Pin	3	65	EPTS-34021-25Q-65	Washer	1
28	EPTS-34021-25Q-28	Washer	1	66	EPTS-34021-25Q-66	O-Ring	1
29	EPTS-34021-25Q-29	Gear Housing	1	67	EPTS-34021-25Q-67	Bushing	1
30	EPTS-34021-25Q-30	Ball Bearing	1	68	EPTS-34021-25Q-68	Spring	1
31	EPTS-34021-25Q-31	Retainer	1	69	EPTS-34021-25Q-69	Handle Bushing	1
32	EPTS-34021-25Q-32	Spring	1	70	EPTS-34021-25Q-70	Hanger	1
33	EPTS-34021-25Q-33	Retainer	1	71	EPTS-34021-25Q-71	Screwdriver	1
34	EPTS-34021-25Q-34	Rear Clutch	1	72	EPTS-34021-25Q-72	Bit ( Option )	
35	EPTS-34021-25Q-35	Ball Holder	1				
36	EPTS-34021-25Q-36	Steel Ball	18	TK	EPTS-34021-25Q-TK	Tune-Up Kit { incl. 3.19 ( 5 ).32.36 ( 18 ).39 ( 3 ).40.44 ( 3 ).47.54.61.63.66.68 }	
37	EPTS-34021-25Q-37	Pilot Pin	1				
38	EPTS-34021-25Q-38	Pin	1				

### FOOTNOTES

10000 SE Pine Street  
Portland, OR 97216  
503-254-6600  
FAX 503-255-2615

When ordering spare parts, please specify  
tool type, part number and description.